

Elite & Compact Reveal Kit – Fitting Instructions



Fig 1 – Existing M8 x 15 Bolts & Nuts



Fig 2 – Bracket (**SG199R0**) with extended bolts attached

Replace Standard M8 x 15 Bolts with the M8 x 19 Bolts (**SG086P0**) provided in the kit at every point there is a stiffening angle, adding in the brackets as Fig. 2



Fig 3 & 4 – Upper Bracket – (**ELITE ONLY**)

Check that bolts are as Fig 4, if not remove & swap over. – (**ELITE ONLY**)

Add extra M8 x 19 Nut & Bolts to Upper Bracket Position – (**ELITE ONLY**)



Fig 5 – Attach the bracket to your reveal



Fig 6 & 7 – Attach Cover Plate (**SG800C0**) and rivet (**WI021WS**) to bracket, use touch up paint on rivets if required.

Mastic all edges to seal & weather proof the cover profile.