

Sectional Door - Site fitting instructions for Manual Handle

The door will be received with the lock fitted to the door panel. The Operating Bar, Latch and Keeper Plate will need to be fitted.

1. Fit the sprung latch on the edge of the curtain.



2. Fit the operating bar on to the lock, lay it next to the latch and mark the end level with the edge of the latch.



3. Cut the operating bar, flatten and drill the end. Bolt on to the latch. Check its operation



4. Fit the keeper plate onto the channel using the two M6 screws provided.

