

THANK YOU FOR PURCHASING AN UHLMANN GIANT UMBRELLA

For the safety and longevity of your umbrella, please
read the OPERATING INSTRUCTIONS and WARNINGS
and follow them carefully!



IMPORTANT OPERATING INSTRUCTIONS:

THE UMBRELLA MUST BE KEPT EITHER FULLY OPEN TO THE "LIMIT STOP" AT THE TOP OF THE MAST (SEE PHOTOS BELOW), OR FULLY CLOSED WITH THE SAFETY STRAP APPLIED.

THE UMBRELLA SHOULD BE CLOSED WHEN STRONG WINDS OR WIND-GUSTS ARE PREDICTED OR CAN BE EXPECTED.

GUTTERS AND SIDE-SHEETS MUST BE REMOVED BEFORE CLOSING THE UMBRELLA.

TO OPEN YOUR UMBRELLA:

BEFORE OPENING YOUR UMBRELLA MAKE SURE THAT THERE ARE NO OBSTACLES IN THE AREA.

- 1) REMOVE STRAPS AND UNWRAP THE FABRIC
- 2) LOOSEN THE UMBRELLA BY LIGHTLY SHAKING THE CANOPY AND THE ARMS.
- 3) INSERT HANDLE INTO GEARBOX AND TURN THE HANDLE CLOCKWISE - DO NOT FORCE THE HANDLE
- 4) GUIDE THE UMBRELLA ARMS TO AVOID FURNITURE AND OTHER OBSTICLES - NEVER FORCE THE ARMS
- 5) TURN THE HANDLE UNTIL UMBRELLA IS FULLY OPEN - **THE RED "LIMIT STOP" ON THE SQUARE TELESCOPIC SECTION SHOULD TOUCH THE TOP OF THE MAST.** FORCING THE WINDING PASSED THIS POINT WILL BREAK THE SAFETY SCREW.
- 6) REMOVE THE HANDLE TO PREVENT UNAUTHORIZED HANDLING
- 7) WHEN USING HEATERS OR LIGHTING, SWITCH THE POWER SUPPLY ON.



WARNING

UMBRELLAS SHOULD BE CLOSED, COVER ROLLED UP AND SAFETY STRAP APPLIED WHEN STRONG WIND EXPECTED OR STRONG WIND GUSTS MAY OCCUR

TO CLOSE YOUR UMBRELLA:

BEFORE CLOSING YOUR UMBRELLA MAKE SURE THAT THERE ARE NO OBSTACLES IN THE AREA.

- 1) WHEN USING HEATERS OR LIGHTING, SWITCH THE POWER SUPPLY OFF
- 2) ALLOW THE HEATERS TO COOL OFF
- 3) TURN DOWN THE HEATER ARMS AND WATCH THAT THE HEATER ARMS FOLD DOWN TO THE PROPER POSITION
- 4) INSERT HANDLE INTO GEARBOX AND TURN THE HANDLE COUNTER-CLOCKWISE UNTIL UMBRELLA IS FULLY CLOSED - DO NOT FORCE THE HANDLE
- 5) PULL ALL FABRIC CLEAR OF THE ARMS, ARRANGE THE FABRIC FOLDS TO FACE IN THE SAME DIRECTION THEN WRAP IT OVER THE ARMS.
- 6) SECURE IT WITH THE SAFETY STRAPS PROVIDED TO AVOID FLUTTERING OF THE FABRIC. ABRASION AND PREMATURE WEAR AND TEAR OCCURS ON THE FABRIC IF ALLOWED TO FLOP AROUND IN THE WIND. RUBBING THE COVER AGAINST THE ARMS REPEATEDLY BY THE WIND, WILL ALSO DAMAGE THE FABRIC.



CORRECT WINDING OF THE CANOPY FABRIC:

- 1) AFTER CLOSING THE UMBRELLA PULL OUT THE WHOLE LENGTH OF THE FABRIC BETWEEN EACH ARM.
- 2) WIND THE LENGTH OF THE MATERIAL IN THE SAME DIRECTION AND IN TIGHT LAYERS AROUND THE MAST.
- 3) USE THE SAFETY STRAP TO HOLD THE FABRIC TIGHT AROUND THE MAST.

WARNING

THE MANUFACTURER DOES NOT ACCEPT RESPONSIBILITY FOR WIND DAMAGE OR ANY DAMAGE CAUSED BY FAILURE TO FOLLOW THE INSTRUCTIONS ABOVE OR FOR DAMAGE CAUSED BY THE IMPROPER USE OF THE UMBRELLA

SPECIAL INSTRUCTIONS FOR COLD WEATHER CLIMATE:

- SNOW MUST BE REMOVED FROM THE COVER AND THE GUTTERS BEFORE THE WEIGHT OF THE SNOW COULD CAUSE DAMAGE TO THE FABRIC OR TO THE STRUCTURE.
- DO NOT USE ANY SHARP OBJECT FOR SNOW REMOVAL. CLOSE THE UMBRELLA GENTLY HALFWAY AND THE SNOW WILL SLIDE OFF THE COVER.
- REMOVING SNOW FROM ONE SIDE, WHILE THE OTHER SIDE OF THE COVER IS STILL WEIGHTED DOWN BY THE SNOW COULD BEND THE UMBRELLA AND DAMAGE THE TELESCOPIC PART.
- DO NOT OPEN OR CLOSE YOUR UMBRELLA WHEN THE COVER IS FROZEN. ICE CRYSTALS IMBEDDED IN THE FABRIC COULD CAUSE THE FABRIC TO BREAK.
- WE RECOMMEND THAT YOU STORE YOUR UMBRELLA FOR THE WINTER SEASON UNDER ITS OWN PROTECTIVE COVER, OR IN A CLOSED, UPRIGHT POSITION IN A DRY AND PROTECTED LOCATION.
- WARNING - THE CANOPY MUST BE COMPLETELY DRY BEFORE ROLLING IT UP AND STORING THE UMBRELLA