# Hörmann ProMatic Akku Garage Door Operator

**All the advantages of Hörmann's rail-guided garage door operator now also for garages without electricity**

**Compact dimensions**
**Easy transport**

**Power for up to 40 days**
**Easy overnight recharging**

**Boom-guided operation**
**Patented door latching**

HÖRMANN

**The solution for prefabricated garages and blocks of garages without electricity**

# **ProMatic** Akku garage door operator

**Suitability**
For garage doors with a door leaf size of up to 8 m² or a width of 3000 mm.
Pull and push force: 350 Nm

**Accumulator**
Capacity: approx. 40 days**
Charging time: 5 - 10 h***
Weight: 8.8 kg
Dimensions:
330 x 220 x 115 mm

**Scope of supply**
Drive unit
Dual-button hand transmitter
Accumulator with charging unit
5 m cable
Accumulator bracket,
fitting material

**Solar module** NEW
Optional
Including connecting hardware, 10 m cable and charge controller
Dimensions: 300 x 400 mm

** based on 4 cycles per day and an ambient temperature of 20°C
*** depending on the charging condition

**Operating comfort without mains connection**
Just press a button to open the garage, even without mains connection in your garage. With ProMatic Akku you have your power source in the direct vicinity of the drive unit. Enjoy the operating comfort without the need to recharge the accumulator for up to 40 days.

**Easy accumulator recharge**
Shortly before the accumulator gets discharged, an audible signal will be given. Similar to the recharging of a cellular phone, you just have to connect the accumulator to a power outlet via the charging unit which is included in the scope of supply. The accumulator will be fully recharged overnight and your door drive is ready for operation again. A spare accumulator is available optionally.

**Comfortable recharging by a solar module**
No manual recharging of the accumulator is required when using the optional solar module which can be easily mounted at or on the garage.

**Suitable for up-and-over and sectional doors**
The ProMatic Akku garage door operator fits all standard up-and-over and sectional doors - all makes, old and new.



**Flexible fitting**
Using the 5 m cable, you may place the accumulator almost anywhere in your garage, either mounted on the wall, on the floor or directly at the door's guide rail. The accumulator comes with a special holding bracket and all connecting hardware.

Should your garage not have a second access door, then an external emergency release must be provided.

If you need professional advice - contact us!

5-Year Guarantee* HÖRMANN

*** For warranty conditions, specifications and further information about Hörmann's garage door operators see www.hoermann.com**

(Issue 05.05) 85236 GB/P
Print 07.05